


Frame Channel

The iGala frame can access Frame Channel service which delivers online photos and personalized content directly to the frame. To setup the Frame Channel service:

1. From the Main Menu screen, tap the "Frame Channel" button, which brings up the Frame Channel setup screen as shown below:



2. Follow the instructions on the Frame Channel setup screen:
 - a. Activate your frame by pointing a web browser to igala.framechannel.com from any PC.
 - b. Create a free account or log into an existing account.
 - c. Enter the Activation Code displayed on the screen after logging into your account.
 - d. Press OK to continue.

3. After your Frame Channel account was setup successfully, the frame will display the following screen which shows the content and download status:



4. You can select or de-select the checkbox of "Include this folder in Slide Show" to include or exclude the photos from Frame Channel in the main slide show.
5. After the Frame Channel account is setup, its content will be displayed next time the Frame Channel button on the Main Menu screen is tapped. User can also press the "View" button to start displaying the Frame Channel content.
6. User can press the "Resync" button to refresh the stored content from Frame Channel and restart the sync process.
7. User can press the "Reset" button to clear the Frame Channel account on the iGala frame.
8. Note: To get more information about the online content from Frame Channel, please visit igala.framechannel.com website.